

# KORG

**U.S.A.:** New York  
**CANADA:** Montreal  
**MEXICO:** Mexico City, Guadalajara  
**GUATEMALA:** Guatemala  
**COSTA RICA:** San Jose  
**COLOMBIA:** Bogota  
**VENEZUELA:** Caracas  
**TRINIDAD & TOBAGO:** Port of Spain  
**ECUADOR:** Guayaquil  
**PERU:** Lima  
**CHILE:** Santiago  
**BRAZIL:** San Paulo, Rio De Janeiro  
**ARGENTINE:** Buenos Aires  
**PARAGUAY:** Asuncion  
**EL SALVADOR:** San Salvador  
**ENGLAND:** London  
**FRANCE:** Paris  
**WEST GERMANY:** Marburg  
**NETHERLANDS:** Rotterdam  
**BELGIUM:** Brussels  
**DENMARK:** Copenhagen  
**SWEDEN:** Malmo  
**NORWAY:** Oslo  
**FINLAND:** Helsinki  
**SWITZERLAND:** Bern  
**AUSTRIA:** Vienna  
**ITALY:** Milano  
**SPAIN:** Madrid  
**PORTUGAL:** Porto  
**GREECE:** Athens  
**EGYPT:** Cairo  
**LEBANON:** Beirut  
**SYRIA:** Aleppo  
**SAUDI ARABIA:** Riyadh  
**JORDAN:** Amman  
**CYPRUS:** Nicosia  
**KUWAIT:** Kuwait  
**SOUTH AFRICA:** Johannesburg  
**TAIWAN:** Taipei  
**HONG KONG:** Hong Kong  
**THAILAND:** Bangkok  
**SINGAPORE:** Singapore  
**MALAYSIA:** Kuala Lumpur  
**NEW ZEALAND:** Auckland  
**AUSTRALIA:** Sydney, Melbourne

Overseas Distributors

THE SIZER

PSU-3301

## ELOPE MODIFIERS

ATTACK TIME

DECAY TIME

SUSTAIN LEVEL

RELEASE KBD HOLD

DAMPED

HALF D

RELEASE

ON

## SIGNAL MODIFIERS

KBD VOLUME BALANCE

SIGNAL OUT

RESONATORS

RESONANCE INTENSITY

RESONATOR 1

RESONATOR 2

RESONATOR 3

AMPLITUDE MODULATION

PEAK FREQ MODULATION BY MG2

ON

MODULATION GENERATOR 1 ON

OUT

5VP-P

FREQUENCY

MODULATION GENERATOR 2

OUT

5VP-P

FREQUENCY

INTERNAL ATTACK CONTROL

EXTERNAL RELEASE CONTROL

EXTERNAL MG1 LEVEL CONTROL

EXTERNAL MG1 FREQ CONTROL

EXTERNAL PEAK FREQUENCY CONTROL

5V~+5V GND 5V -5V~+5V -5V~+5V

京王技研工業株式会社  
本社

東京都杉並区下高井戸1-15-12 〒168 Tel.03-325-5691

ショールーム・スタジオ

東京都新宿区新宿7-27-6 〒160 Tel.03-208-5691

関西サービスセンター

大阪市大淀区中津7-5-21 アイオイ第一ビル5階 〒531 Tel.06-452-5691

●規格及び外觀などは、改良のため予告なく変更することがあります。

●価格は別紙「価格表」(昭和55年3月現在)をご参照下さい。